



Installation Instructions: TR-0021

05-07 Ford Super Duty

Rigid Dually XL Adapter Brackets



The TR-0021 Adapter Brackets for 05-07 Ford Super Duty Trucks allows you to install a set of Rigid Industries Dually XL lights into onto the factory fog light brackets. No Drilling is required, this is a 100% bolt-on installation!

1. Remove the factory fog light brackets from the inside of the bumper by first unplugging the fog light from the factory wiring. Remove the 3 bolts holding each bracket onto the inside of the bumper and pull the assembly out. It is possible to do this without removing the bumper.
2. Remove the factory fog light from the plastic bracket by removing the two screws holding the back tabs in, and removing the adjustment screw with spring on the bottom. You will not re-use these items. Once removed, you will be left with the factory bracket as shown in PHOTO 1. The KD Fabworks brackets are offset to one side; the bracket set shown in **PHOTO 1** is the passenger side.
3. Place the new KD Fabworks bracket onto the OE bracket, lining up the single hole on the lower tab with the same hole that the factory adjustment screw and spring came out of. Loosely secure using the supplied M5x30 stainless button head bolt, washers, and nyloc. See **PHOTO 2**.
4. Loosely secure the two tabs on the back side of the OE bracket using the supplied M6x20 stainless button head bolts, washers, and nylocs. See **PHOTO 3**.
5. Tighten down the M5 bolt first on the bottom tab, followed by the two M6 bolts.
6. Install the Rigid Dually XL onto the KD Fabworks bracket using the hardware included with the light. See **PHOTOS 4 & 5**.
7. Plug the KD Fabworks adapter harness into the back of the Rigid Light.
8. Reinstall the whole assembly back into the vehicle and secure with the factory bolts removed in step 1, and plug the adapter harness into your factory fog light wiring.



Thank you for purchasing a product from KD Fabworks!