



Installation Instructions: TR-F150-03

2015+ Ford F150

Pod Light Adapter Brackets



The TR-F150-03 Adapter Brackets for 2015+ Ford F150 Trucks allows you to install a set of Rigid Industries Dually or import pod lights into the factory fog light buckets. No Drilling is required, this is a 100% bolt-on installation!



1. Unplug the wiring harness from the back side of the bulb from under the front bumper. Remove the white cap on the adjustment screw. With a phillips screwdriver, remove the adjustment screw. The spring will come out once screw is removed. Using a flat head screwdriver, pry out on the side clips to release the factory fog light housing. Side clips shown in PHOTO 1
2. With the factory fog light removed, you can place the KD Fabworks bracket in place. The OE bucket is tapered, so the KD Fabworks bracket will only go in one way. The square opening on the KD Fabworks bracket will line up with the opening in the back of the OE bucket. OE Bucket with OE fog removed shown in PHOTO 2
3. Insert a 3/8" stainless steel button head bolt with washer from the inside through the KD Fabworks bracket and the side holes that previously held the OE fog light. Push the KD Fabworks bracket back as far as you can against the back of the OE bucket, and tighten the bolts with washers and nyloc nuts shown in PHOTO 3
4. Install your Rigid Dually light, or other pod light by inserting the plug/wiring through the square pass-through opening in the KD Fabworks bracket. Loosely attach the light to the KD Fabworks bracket using hardware supplied with your light. Center the light top to bottom as best as you can and tighten the bolts. See PHOTO 4 & 5
5. Plug the KD Fabworks adapter harness into the light wiring, and then into your OE fog light wiring plug.
6. Repeat for other side.



Photo 1



Photo 2



Photo 3



Components for one side shown



Photo 5



Photo 4

Thank you for purchasing a product from KD Fabworks!

KD Fabworks
www.KDfabworks.com
888.535.1580



© KD Fabworks 2015